



# ASSEMBLY INSTRUCTIONS CABINET HARDY

# ZUIVER<sup>o</sup>




## Parts Check List

Code	Components	Qty
Ⓐ	BODY	x01
Ⓑ	SHELF	x02


## Hardware Check List

code	description	qty
01	Metal bracket	x04
02	Screw	x04
03	Plastic strap	x02
04	Nylon wall strap	x02





- PLEASE DO NOT DISCARD ANY OF THE PACKAGING UNTIL YOU HAVE CHECKED ALL THE PARTS AND THE PACKS OF HARDWARE.
- BEFORE YOU BEGIN TO ASSEMBLE YOUR NEW PIECE OF FURNITURE, PLEASE CHECK TO ENSURE THAT ALL PARTS HAVE BEEN SUPPLIED.
- FOLLOW INSTRUCTIONS CLOSELY AS DEVIATION FROM THEM MAY VOID YOUR WARRANTY AND PRESENT A POSSIBLE SAFETY RISK.
- IT IS RECOMMENDED THAT ASSEMBLY IS DONE ON A SOFT SURFACE LIKE CARPET TO AVOID ANY DAMAGE.
- PERIODICALLY CHECK AND RE-TIGHTEN ANY FASTENERS. WIPE DOWN ALL SURFACES WEEKLY WITH A CLEAN CLOTH. DO NOT CLEAN ANY SURFACES WITH HARSH ABRASIVES OR CHEMICALS.


Tools required  
Not supplied



1.




2.





3.



Back view



4.




5.




# ASSEMBLY INSTRUCTIONS HINGE ADJUSTMENT


# ZUIVER<sup>o</sup>




The door will not be flush with the side panel.




**Side to Side Adjustment**  
loosen screw A, adjust gap with screw B and re-tighten Screw A.




The door will appear too far or too close from the front edge of the side panel.



**Depth Adjustment**  
loosen screw A, push hinge arm forwards or backwards, re-tighten screw A and secure Screw B with a 1/4 turn clockwise.



The door will not be flush with the vertical panel.



**Height Adjustment**  
loosen screw C, adjust door height and re-tighten screw C.

\* The doors can be adjusted in all 3 directions to create an even fit between doors on this cabinet. Follow the appropriate directions above to adjust door(s) as necessary.