


Instructions

- 1. Move the hands to the correct time using the adjustment wheel on the back of the clock mechanism.
- 2. Insert 1x AA/LR6 battery (not included), as illustrated. We recommend the use of top condition, branded, alkaline batteries. Old or poor quality batteries may cause your clock to lose time/stop.



3. Where a clock is to be wall mounted, please ensure an adequate wall fixing is used to hang your clock, taking into account the type of wall and weight of the clock.

Care and Caution

Please keep your clock out of direct sunlight. When you come to clean your clock please use a soft dry cloth as the use of liquids and cleaning agents may damage the finish.